Mike Zecchino, Shawn McDermed

Thin, transparent domes require an on-axis Fizeau with a short coherence measurement source.

# Measuring Transparent Domes with a Short Coherence Laser Interferometer

# Introduction

Thin, transparent domes are used in surveillance, aerospace and defense applications to enclose and protect imaging and guidance systems. Since these components are always in the optical path, instrument designers and fabricators need to establish proper tolerances and characterize the manufactured dome glass shape and thickness variations carefully to maintain accurate imaging.

A Fizeau configuration laser interferometer is typically the instrument of choice for measuring critical optical components such as these. Its large aperture makes it possible to image and test large areas of the convex dome surface in one measurement, with sufficient resolution to discern fine surface variations and imperfections.




Figure 1. Measuring transparent domes is difficult because of reflections from both surfaces as well as the steep curvature. An on-axis Fizeau interferometer with a "surface isolation source" makes it possible to measure domes, including the surface shape, transmitted wavefront quality, optical thickness and radius of curvature.

# The challenge of measuring thin transparent optics


An interferometer measures surface height by comparing the shape of the test optic against a high quality reference surface. The measurement beam is split in amplitude to produce two beams. One is directed to the test optic and the other reflects from the reference surface. When the beams recombine they create a pattern of interference fringes (Figure 2, left). The shape of a fringe is directly related to height variations on the test part compared to the reference surface. While carefully shifting the position of the reference surface by small increments, several interference patterns are acquired from which the shape of the test surface can be determined with high precision.

A transparent dome presents several challenges for interferometric measurement, however.

A typical Fizeau interferometer uses a long coherence laser source. With this standard source, interference fringes are generated between any reflective test



surface parallel to the reference surface. When measuring thin, parallel transparent optics (windows, domes, glass disks, etc.), interference will occur between all of the reflective surfaces, resulting in a complex interference pattern from which it is difficult or impossible to determine the shape of the test surface (Figure 2, right).






Figure 2. With an interferometer, surface heights and transmission errors are determined from a series of interference patterns. The image on the left shows an interference pattern using the short coherence source. With a standard source (right) both disk surfaces cause interference, resulting in the complex interference pattern.

To isolate and measure the individual surfaces of such an optic it was traditionally necessary to apply an anti-reflective coating to the back surface, thereby eliminating the extra interference fringes. After measurement, the optic would be cleaned, the other side coated, and another measurement taken of the second surface. The process is time-consuming and can potentially be detrimental to the optic, especially when fragile coatings have been applied.

# A short coherence source isolates the surfaces

In recent years interferometers have been developed that combine a short coherence source with an adjustable path-match mechanism. The path-match mechanism can be tuned either manually or automatically to selectively interfere any combination of surfaces within the test path. Such a "surface isolation source" makes it possible to isolate and measure the front and back surfaces of transparent components as thin as 50 microns. Both measurements can be completed without repositioning the optic, which reduces measurement time and eliminates potential misalignment between the two measurements.

The surface isolation source can also be applied for measuring curved surfaces and is ideal to test radially concentric, transparent domes. In this case, rather than using a flat reference surface, a transmission sphere with approximately the same F/# (i.e., curvature) as the dome is used as the reference.

Figure 3 shows this measurement setup with a Fizeau interferometer. The transmission sphere can be seen on the front of the instrument. The test dome is mounted in a separate 5-axis mount for accurate positioning.





Figure 3. A Fizeau interferometer setup for measuring a transparent dome.


The surface isolation source enables each surface to be isolated and measured sequentially, without re-fixturing the part. As shown in Figure 4, adjusting the pathmatch distance isolates either the outer or inner surfaces for measurement.

# Measuring the near surface



Coherence path-match distance matches near surface

# Measuring the far surface



Coherence path-match distance is moved to match second surface

Figure 4. Setups for measuring the outer and inner surfaces of a thin, transparent dome.



Figure 5 shows the interference fringes and measurement results for the two surfaces illustrated by the test setups of Figure 4:





Figure 5. The interference fringes and measurement results for the inner and outer surfaces.

From these two measurements it is also possible to obtain accurate maps of both surfaces and the optical total thickness variation (OTTV) across the measurement area. The variation can be calculated by subtracting the inner surface measurement from the outer surface measurement. Scaling the OTTV result by the material index of refraction yields the physical thickness variation.

Alternatively, OTTV can be measured by setting the path-match distance such that interference occurs between the front and back dome surfaces, rather than with the reference surface. Such a "solid cavity" test (Figure 6) can be more reliable as it eliminates any degradation due to air turbulence or thermal currents.

# Measuring differences between the surfaces



Coherence path-match distance set to nominal thickness of dome

Figure 6. A "solid cavity" test produces interference between the front and back dome surfaces, rather than with the transmission sphere. This enables a comparative thickness (OTTV) measurement that is unaffected by air turbulence.

# **Measuring Radius of Curvature**

A Fizeau interferometer can also be used to measure the radius of curvature of a dome. By measuring the dome, first at the cat eye and then at the confocal position, the radius of curvature can be measured accurately. A high precision stage is used to control and adjust the sample location relative to the interferometer for the two measurements.

Figure 7 shows a Fizeau interferometer in a vertical, look-down configuration with a precision positioning stage.



Figure 7. A Fizeau interferometer in a look-down configuration with a precision positioning stand.

# **Considerations for dome measurements**

A critical assumption implicit in the use of a Fizeau interferometer is that the reference and test beams follow nominally identical paths through the instrument's imaging optics. As a result, aberrations and thickness variations in the system's internal optics cancel out, and therefore they do not add significant error to the measurement. If the test configuration is "off axis" and tilt is introduced between the test and reference beams, then any errors in the optical train will appear as errors in the measurement result as well.

When measuring a flat optic, the errors introduced are typically negligible and do not impact measurement accuracy. However, when measuring a strongly curved surface such as a non-spherical dome, the errors become significant and can distort the measurement data. An on-axis, Fizeau interferometer is therefore the preferred instrument for measuring domes.

Measurement setup time is another important consideration. The path-matching operation can be automated. Figure 8 shows the result of such a scan. Note the two sharp modulation peaks at approx. 93 mm (interference between the outer dome surface and reference) and 99 mm (interference between the inner dome surface and reference). Once the software-controlled path-match scan is complete, an operator can select the surface of interest to test, fine tune the scan at the appropriate peak, and acquire the measurement.





Figure 8. The path-match mechanism automatically locates the position of all surfaces in the optical path.

# Conclusion

Measuring the shape and thickness of transparent domes is a challenging application that can be accomplished with very few instruments. A short coherence source Fizeau interferometer is an ideal solution, providing the ability to selectively isolate the dome's outer and inner surfaces. Both surface quality and total thickness variation can be measured for radially concentric, spherical domes. The same technology can be used to measure a variety of thin, transparent optical elements such as windows, glass disks, etc.

# Isolate and measure both surfaces of thin, transparent domes and flats



4D Technology's AccuFiz D Fizeau laser interferometer combines a fully on-axis design, vibration insensitivity and short coherence source to measure transparent optics. Measure both surfaces, wavefront error and optical thickness variation in a single measurement setup.

Click here for the AccuFiz D Fizeau Interferometer Data Sheet

A lightweight, portable, and extremely versatile Fizeau for shop-wide measurement of flats, spheres, prisms, wafers, transparent optics and more.

4D is the first name in dynamic metrology.

4dinfo@ontoinnovation.com (520) 294-5600 www.4DTechnology.com

