

PROMON 2000 Bundle

High Speed Streaming System – ready-to-go



Forget limited recording time

Stream directly to non-volatile memory with 1920x1080 @ 1000 frames/sec

Read-to-go

PROMON 2000 Bundle comes with 2TB non-volatile memory ready to record for 30 mins

High Speed – High Dynamic

Record with 1000fps 8Bit or with 300fps up to 12 bits dynamic range

User friendly

Imaging Studio V4 for recording and post processing pre-installed on High Speed Video Recorder

PROMON 2000 Bundle – what you get for an unbeatable price!

Camera	PROMON 2000 camera monochrome 1920 x 1080 pixel for 1000fps – 8Bit or 300fps – 12Bit (adjustable in SW) with all accessories. Higher framing speed when reducing resolution. Camera details see here
Recorder	High Speed Video Recorder with WIN IoT and Imaging Studio V4 pre-installed. Available languages English / French / German / Korean / Spanish / Chinese / Portuguese 2TB non-volatile memory (approx. 30mins recording with full resolution, max. fps) Fits in the palm of your hand (size 130 x 125 x 55mm)
Converter Box	Converter from 10Gigabit Ethernet to Thunderbolt for interfacing to High Speed Recorder
Accessories included	All necessary cables for Recorder and Converter, power supplies, 5m (15ft) cable from camera to Converter, all packed in a Pelican style box with foam cut inserts and space for extras.
Optional items	Lenses, light and other accessories, please inquire
User supplies	HDMI Monitor, Keyboard, Mouse, accessories such as lenses, light etc.
Ordering information	AOS# 591112-00-0000 PROMON 2000 Bundle